

Nastavitve \$ prefix za Metrologic MS9540


Recall Defaults




Zgornja koda za reset na
tovarniške nastavitve



Enter/Exit
Configuration Mode



~ Configurable Prefix
Character #1



Code Byte 0



Code Byte 3



Code Byte 6



Enter/Exit
Configuration Mode

